



1983-1987 G SHIFT CONTROL/AUTOMATIC TRANSMISSION FLOOR

1.	4.010	BRACKET , SHIFT LVR (EXC MW9)(1983-87).....	559977
4.010		BRACKET , SHIFT LVR (W/MW9)(200-4R).....	22508097
2.	4.017	RING , HDL-RH.....	560888
4.017		RING , HDL-LH.....	560887
3.	4.006	HANDLE , SHIFT LVR (BLU)(1983-84).....	22517551
4.006		HANDLE , SHIFT LVR (BLU)(1985-88).....	22525554
4.	4.008	SPRING , HANDLE	560891
5.	4.015	SLIDE , SHFT LVR HANDLE BTN.....	560890
6.	4.006	BUTTON , HANDLE.....	560886
7.	4.017	RING , SHFT LVR HDL TR LWR	560889
8.	4.008	PIN , LVR TO BRACKET	559980
9.	8.900	BOLT , HWH (M6-1 X 20) PZOR	11508600
10.	8.915	NUT , HEX (M10-1.5)	11505057
11.	8.929	WASHER , FLAT 15/32 X 15/16 X 1/16 ZP (AR).....	120395
12.	4.047	PIN , CONTROL CABLE.....	14105773
13.	8.929	WASHER , RAD.....	507295
14.	4.047	RETAINER , TRANS CONTROL CABLE (1/4" SPRING RET)	9791366
15.	4.045	LEVER , CONT RANGE SEL.....	10026214
16.	4.047	BRACKET , RANGE SEL LVR CBL LWR (MW9)(200-4R)	10027568
4.047		BRACKET , RANGE SEL LVR CBL LWR (MV9)(200C).....	10001413
17.	4.047	SPRING , RANGE SEL LVR CBL	10022571
18.	8.900	BOLT , HEX (M8-1.25 X 20) PZOR	
19.	4.047	CABLE , RANGE SEL LVR (M31/MV9).....	22500579
4.047		CABLE , RANGE SEL LVR (MW9).....	25537476
20.	4.047	GROMMET , RNG SEL LVR CBL	10002808
21.	8.977	SCREW , HWH TAP (M4.2 X 1.41 X 16) PZOR.....	11509135
22.	8.915	NUT , HEX (M6-1)	11507095
23.	N.S.	HANDLE , (SEE VIEW A)	
24.	4.006	RETAINER , HANDLE TO SHIFT LEVER.....	10028352
25.	4.045	EXTENSION , SHIFT LEVER ROD.....	559978
26.	4.020	PLATE , SHIFT LVR INDEX (M31/MV9)	559981
4.020		PLATE , SHIFT LVR INDEX (MW9)(200-4R)	22508098
27.	4.006	LEVER , SHIFT.....	562947
28.	4.037	SLEEVE , SHIFT PIN	562948